

Tower Automatic Bypass Valve

Tower Controls

**SWITCH ON
TO COMFORT**



Regulates heating system differential pressure
 High capacity flow up to 50 litres per minute
 Differential pressure range 0.1 to 0.6 bar
 22mm compression fitting

The Tower ABV should be fitted where a boiler bypass is required – typically this is the case when a system is equipped with thermostatic radiator valves (TRV's), and to allow pump overrun operation after zone valves have closed down.

TRV's slowly close down as each radiator raises the room temperature. To overcome flow restriction as TRV's close down, the ABV is adjusted to the required set point. As the system resistance increases due to TRV's closing, the ABV allows flow to increase, in order to maintain the required pre-set system differential pressure. The regulation provided will reduce system noise that can result from TRV's or zone valves closing, eliminate pump impeller wear that can result from high flow resistance, and enhance the life of the boiler's heat exchanger by ensuring minimum flow rate at all times.

Installation should be in a loop between flow and return after the pump. Ensure that the flow is in the direction of the arrow on the ABV body. Rotate the adjustment head until the required setting number is visible, and lock the valve at that point by tightening the screw on top of the adjuster. Refer to recommendations in the boiler instructions and the pressure / flow rates detailed below to decide which setting is required.

Specification

- High capacity flow up to 50 litres per minute
- Wide differential pressure range 0.1 bar to 0.6 bar
- 22mm Compression fittings
- Reduces system noise
- Maintains an even system pressure
- Constant flow through boiler
- Lockable set pressure

